Grid (1 , 1)


warn, when beyond
the limit
soft start
current
limit
DC-current
Lasertreiber, v2.3, Elekt
current
modulation
CONN1
CONN2
CONN9
1R1
3U1
3U5
1Q1
1R14
1S1
1PAD1
1D3
1L1
3L1
3R5
3R14
J1
J5
R98


ktronIQ, 04/2016 -<(kmk)>-
switch
integrator
mode
measure temperature
current
monitor
PI
voltage
reference
RESET
GND
CONN5
CONN7
CONN8
2S1
2U12
U8
U13
S1

Grid (1 , 1)


warn, when beyond
the limit
soft start
current
limit
DC-current
Lasertreiber, v2.3, Elekt
current
modulation
F/UCLW12
100uH
1000uF
100uF
1R2
1R_3W
BSS123
Jumper
JMP
49R9
LL4148
BC857C
1N4001
LED_3mm_red
LED 2mA green
XXX
PS-25/56-BR
Spectrol 534, 10k
BNC-lay
LM317T
IRF9520N
47R_ISA-Plan-PBH
APEM_TL46WW
NE5534
TLE2141
MGF44061


ktronIQ, 04/2016 -<(kmk)>-
current monitor
measure temperature
switch integrator mode
PI
voltage reference
RESET
D-SUB BU 09P
BNC-lay
D-SUB ST 09P
Apem TL36WW TDA2030AV
7915
7815
MS500FVT
Relay FRS5 12V
BAV103
SL11/124
NTC_Resistance
peltier-
LED_3mm_red
LED_3mm_green
FSMJ-9.5mm
1N4001
1000uF/25V
1000uF/16V
PS-3pin
XLR-male-3pin
1xJUMPER
GND
JMP


2R64


3R12


10k


10R